



"If we wish to work with a prototype that behaves similarly to an artery, it must have elastic properties. Printers that work with only rigid materials would not be functional for this use."

Dr. Tiago Senra / Dante Pazzanese Cardiology Institute

The Dante Pazzanese Cardiology Institute merges 3D printing technology and MRI and CT scans to determine future patient treatment.

CASE STUDY

Heart Smart DANTE PAZZANESE CARDIOLOGY INSTITUTE USES 3D PRINTED ARTERIES TO DIAGNOSE AND TREAT DISEASES

The Dante Pazzanese Cardiology Institute (DPCI) is using 3D printing to help diagnose and treat cardiac disease. Established in 1954 and internationally renowned for specializing in the treatment of severe cardiac conditions, the hospital and research center has been using an Objet®350 Connex™ multi-material 3D printer since 2012. A multidisciplinary team of doctors and engineers use it to print 3D prototypes of a patient's arteries, and to use those models to test how a patient's artery will behave during a catheterization procedure.

DPCI is both a hospital and research center administrated by the São Paulo State Secretariat of Health. With 1,500 employees and 300 hospital beds, DPCI helps in the diagnosis, treatment and research of complex cardiac cases.



3D Printing Used in Cardiology

While 3D printing in areas such as orthopedics, trauma and neurosurgery is widespread, Dr. Tiago Senra of the cardiovascular MRI and CT scanning department says cardiology is another story, due to complicating factors. First, blood vessels are difficult to identify in imaging tests. "To enable image diagnostics, we inject contrast in the veins or arteries," explains Dr. Maximilliam Gospos of the cardiovascular MRI and CT scanning department.

Also, because the heart is constantly beating, MRI or CT scans must be synchronized with an electrocardiogram to render static images of the veins and arteries.

However, DPCI is already using 3D printing technology to help its patients. DPCI chose an Objet350 Connex because of its multi-material and high-precision capabilities. "The ability to print a prototype of an artery in rubber is very important to us," emphasizes Senra. "If we wish to work with a prototype that behaves similarly to an artery, it must have elastic properties. Printers that work with only rigid materials would not be functional for this use."

According to Bruno Utiyama da Silva, researcher and coordinator of the 3D printer projects at DPCI, the flexible material gives the doctors and engineers of Dante Pazzanese freedom to create new uses and solutions using the 3D printing technology. "We also use this machine in the process of developing heart pumps, which demands materials very different to those used in the blood vessel prototypes," explains Utiyama.

Assessing Surgery Risks

The external 3D anatomical model of the patient allows the doctors of DPCI to study the conditions of the pathology and then decide which treatment to pursue. The tests carried out on 3D printed arteries will reveal whether performing a catheterization is safe or not. With the 3D printer's help, it is possible to study a patient's specific blood vessel without the need for invasive procedures.

To reduce the risks of patients being subjected to catheterizations, DPCI uses the 3D printer to 3D print the arteries of the patients. "The aim is to perform tests, before the catheterization, to see if it is worth performing this procedure or not," says Senra.

To perform these tests, both the patient's artery and an "umbrella" are printed simultaneously. The umbrella is an embolic protection device implanted in the artery before the catheter is inserted. "By adjusting the umbrella in the artery, we can be certain that the embolic protection device will, in fact, cover the area of the entire vessel," says Gospos. "If that doesn't happen, there is a risk the catheter will touch the walls of the vessel and dislodge embolisms. This could lead to problems for the patient."



Bruno Utiyama da Silva, researcher and coordinator of 3D printer projects, says the flexible material opens up new possibilities for cardiac solutions.



The Objet350 Connex's rubber-like material is ideal for prototyping arteries.



3D printed models are used to assess surgery risks to patients.



Dr. Tiago Senra of the cardiovascular MRI and CT scanning department instructs on cardiac 3D prototypes.

stratasys

What Gospos describes is distal embolization – when the catheter insertion dislodges small plaques from the walls of the vessels. These plaques can lodge in small vessels such as brain arteries where they could cause a stroke. A stroke can lead to serious complications, such as loss of strength in limbs and facial muscles, aphasia and sometimes death, so it's important to correctly determine if a catheterization is right for any given patient.

The DPCI team can now prototype a patient's vessels, study the catheter passage, analyze the risk of embolisms and determine whether to recommend catheterization.

"We use 3D printed prototypes of the artery and umbrella to simulate how the catheter insertion would take place and if the vessel walls would be protected during the entire procedure," said Senra. "The 3D printing technology helps us separate patients who are able to go through the procedure from the ones who aren't."



Dr. Maximiliam Gospos of the cardiovascular MRI and CT scanning department explains how scans are used to create 3D models.



The Objet350 Connex 3D Printer's range of materials proved beneficial to the Dante Pazzanese Cardiology Institute.



E info@stratasys.com / STRATASYS.COM

ISO 9001:2008 Certified

HEADQUARTERS

7665 Commerce Way, Eden Prairie, MN 55344 +1 800 801 6491 (US Toll Free) +1 952 937-3000 (Intl) +1 952 937-0070 (Fax) 2 Holtzman St., Science Park, PO Box 2496 Rehovot 76124, Israel +972 74 745 4000 +972 74 745 5000 (Fax)

©2014, 2016 Stratasys Inc. All rights reserved. Stratasys, Fortus, uPrint, Objet350 Connex and FDM are registered trademarks and the Stratasys logo, "For a 3D World", and FDM Technology are trademarks of Stratasys Inc. ULTEMTM is a registered trademark of SABIC or affiliates. All other trademarks are the property of their respective owners. Product specifications subject to change without notice. Printed in the USA. CS_PJ_ME_DantePazzanese_0116